





Note 1

1 way valve must be between pump and Vacuum switch

NOTE 2

Vac motor has rubber rotor and vanes for quiet running
running time should be kept to a minimum to maintain pump longevity
Once vacuum has built up, pump should run for about
3 to 8 seconds for every three pedal presses

Simtek UK		
Vacuum pump system		
Jay Simkins	Rev 1.8	Page 1
	12/05/2018	



Simtek UK		
Vacuum pump system		
Jay Simkins	Rev 1.0	Page 1
	12/05/2010	

